Smart Dupline[®] PIR Sensor for Ceiling and Luxmeter Type SHSQP360L



SH SQ P 360 L



- Passive infrared detector (PIR) with built-in luxmeter
- Detects movement and presence
- Light measuring range: 0 to 20 klux
- Indoor applications
- Smart-house output
- Operating distance: max. 7.5 m
- Operating angle: 360°
- LED indication
- Supplied by bus
- Ceiling-mount

Product Description

The SHSQP360L is a 360° PIR sensor to detect presence and/or movement in indoor installations with a built-in luxmeter, combining two products in one. It is part of the smart-house concept and can be used to control lights, rollerblinds, air-conditioning, intruder alarms and all the other functions supported by the smart-house system, in an automatic way depending on people-presence. This sensor is completely programmable via the SH tool.

Ordering Key

smart-house Ceiling mounting			
Detection angle			

Type Selection

Housing	Colour	LEDs	Supply by bus
Ø 90 x 40 mm	White	1 blue	SHSQP360L

Input Specifications

Inputs Lens Angle	PIR Dual detecting zones 360°	
Operating Distance	≤ 7.5 m	
Luxmeter Characteristic deviation	-3% to + 3%	
Response time	It depends on the number of variables in the system	
Sensor range	0 to 20 kLux	
Output accuracy over temperature	0° to 40°C ± 10% -30° to 0°C ± 15% 40° to 60°C ± 20%	

Dupline® Output Specifications

Voltage	8.2 V
Maximum Dupline® voltage	10 V
Minimum Dupline [®] voltage	5.5 V
Maximum Dupline [®] current	5 mA

Output Specifications

Dutput LED output	Blue LED

Supply Specifications

Power supply

Supplied by bus

CARLO GAVAZZI

Address assignment controller **CE Marking** Yes Automatic: the recognises the module EMC through the SIN (Specific Immunity EN 61000-6-2 Identification Number) that - Electrostatic discharge EN 61000-4-2 has to be inserted in the SH - Radiated radiofrequency EN 61000-4-3 tool. - Burst immunity EN 61000-4-4 Environment EN 61000-4-5 - Surge IP 20 - Conducted radio frequency Degree of protection EN 61000-4-6 Pollution degree 3 (IEC 60664) - Power frequency magnetic 0° to +50°C (+32° to +122°F) Operating temperature fields EN 61000-4-8 Storage temperature -20° to +70°C (-4° to + 158°F) - Voltage dips, variations, Humidity (non-condensing)20 to 80 % interruptions EN 61000-4-11 EN 61000-6-3 Emission Connection - Conducted and radiated Screw terminals 0.2 to 1.5 mm² CISPR 22 (EN55022), cl. B emissions D+ Signal - Conducted emissions CISPR 16-2-1 (EN55016-2-1) D-GND - Radiated emissions CISPR 16-2-3 (EN55016-2-3) Dimensions OPUS (WxHxD) Ø 90 x 40 mm Weight 25 g

General Specifications

Mode of Operation

This PIR sensor responds to any fluctuation in infrared heat radiation, so any object or human presence changes the thermal image detected by the sensor when entering its field of vision.

The sensor is equipped with a segmented lens that divides the field of vision into active and passive zones (zones not visible to the sensor, see figure "Sensitive area"). When a heat source crosses these zones, the sensor detects the change in infrared radiation and presence and/or movement are recognised.

How sensitive and fast the sensor has to be to detect presence and/or movement can be programmed by means of four parameters, by means of the SH tool.

The four parameters are: mode of detecting the

crossing of active zones, sensitivity, the number of pulses and the time window in which these pulses have to be detected. These four parameters have to be set for both presence and movement recognition.

Movement is used by the system in the intruder alarm function and to switch the light on, while presence is used in the light function to reload the energy-save timer (i.e. each time presence is detected, the energy-save timer starts counting from the beginning).

1) Mode of detection

A: one border between the active and the passive zone has to be crossed to give a pulse signal. This option has to be selected for presence detection and movement and turns the light on as

soon as a person moves from an active to a passive area or vice versa (very quick response).

B: two borders have to be crossed to give a pulse signal. The person has to move from an active area to another active area, passing through a passive one or vice versa.

This option is recommended for sensors used in the intruder alarm function, in order to avoid false alarms.

2) Sensitivity

A number can be set from 3 to 100: the smaller this value is, the longer the detection distance, but the higher the sensitivity to heating sources.

In the figure "Sensitive Area", examples of different sensitivity can be seen.

3) Number of pulses

The number of pulses is calculated according to mode A or B before sending a people detection message to the controller. This can be set from 1 to 8.

4) Time window

This is the time interval within which the predefined number of pulses is detected. It can be set from 1 to 10 seconds.

In the table below is an example of settings which, of course, might depend on environmental conditions, application and type of installation.

	Presence	Movement (light fx)	Movement (alarm fx)
Mode of detection	A	A	В
Sensitivity	1030	3070	50100
Number of pulses	1	1	3
Time window	10	2	10



Mode of Operation (cont.)

LED programming

There is one configurable LED (blue) on board the SHSQP360L to be programmed.

Blue LED: the user can select one of the following options: 1.LED always OFF

- 2. LED flashes shortly every seconds if a presence/ movement is detected
- 3. LED flashes shortly every seconds if it is used as feedback of a function status
- If the blue LED is not programmed, it is always OFF.

Coding/Addressing No addressing is needed since the module is provided with a specific identification number (SIN): the user has only to insert the SIN number in the SH tool when

creating the system config-

uration.

Used channel: 2 input channels, 1 output channel.

Active and passive zones



Sensitive area





Mounting

The PIR detector is designed for ceiling mounting. As the SHSQP360L is a passive device, several detectors can be placed in the same room without interfering with each other. The module should not be installed as follows: a) Outdoors.

a) Outdoors.
b) In places exposed either to sunlight or to motor vehicle headlights pointing directly at the sensor.
c) In places exposed to direct air flow from a heater or air conditioner. d) In places where rapid temperature changes occur. e) In places exposed to severe vibration.

f) Close to glass or other objects which might reflect the infrared radiation. **Note:** If the sensor is to detect presence, please be careful to mount it so that the area where presence has to be detected is completely covered by the sensitive area of the sensor. See figure "Sensitive area".

Wiring Diagram



Dimensions

